



## **32MM RAIN DEFLECTOR**

- 1) With the door in the closed position, cut the rain deflector to the width of the door, allowing 3mm clearance on the catch side.
- 2) Mark the position of the screw holes when the rain deflector clears the threshold sill by 9mm.
- 3) Apply sealant in the sealing grooves of the deflector and screw to the door.