

Mortice Preparation for Tubular/Deadbolt

Unless specifically stated in the manufacturers installation instructions for the tubular latch/deadbolt, all morticing should be central to the door edge.

The mortice must always be aligned horizontally and vertically in order for all relevant components to operate as intended. Misalignment of any single component can lead to the breakdown of complete door set operation.

Using a pencil, mark the door edge for the height and width of the mortice, and also for the forend. Use these markings as your visual guide to ensure you cut the mortice to the correct dimensions.

Note: If any internal components become proud of the tubular body during each operation, this extra measurement should be calculated into the mortice dimension requirement.

On either face of the door, mark any required hole centres for follower and accessory bolt through fixings.

Any mortice should be cut out as smoothly as possible and any shavings or swarf must be cleaned out prior to installing the product.

Where additional holes are required through the door face, these must be done without anything in the mortice, again removing any shavings or swarf.

It is recommended to pilot all fixing screw locations prior to final fitting to prevent excess strain on the fixings.

