

CAR COVERS
AND SHELTER



Single Quickshade Assembly
Car Covers and Shelter

STEPS FOR QUICKSHADE ASSEMBLY

Single Quick Shade Check List

1. 4 x 1480mm swaged down tubes
2. 6 x 1650mm swaged & bent down tubes
3. 4 x 850mm swaged spreaders
4. 2 x 600mm swaged middle spreaders
5. 1 x 1480mm swaged centre pieces
6. 1 x 1480mm Y piece (not swaged)
7. 1 x 1550mm swaged Y piece
8. 2 x 250mm peg cut @ 13 degree no swage

Single Quick Shade Assembly Instructions

Step 1



Step 2



Step 3



Step 4



Step 5



Step 6



Step 7



Step 8



Step 9



Step 10



Step 11



Step 12



info@carcoversandshelter.com.au
Ph: 1300 851 038