
Canvacon









POSITION THE HOLD DOWN PEGS



DRIVE IN THE HOLD DOWN PEGS



ASSEMBLE THE BASE RAILS



ATTACH THE PORTAL FRAMES



INSERT THE SUB FRAME (NO LADDER REQUIRED)



POSITION COVER



LIFT MAIN FRAME



SHED COMPLETED

info@carcoversandshelter.com.au 1300 851 038