



**INSTALLATION INSTRUCTIONS FOR  
NO DRILL LICENSE PLATE MOUNT  
FERRARI SF90 STRADALE**

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

**Tools Required:**

Phillips head (star) screwdriver (for North American installs)

**Kit includes:**

Pre-assembled front license plate mount

**North American License Plates**

Using a Philips head (star) screwdriver affix your license plate to the mount using the two screws provided. Note: These screws should be long enough to accommodate most aftermarket license plate frames and there is no issue using a plate frame or cover with the Carbonio mount.

**Rest of World (ROW) License Plates**

Rest of world cars have their license plates adhered to the plate mount using high strength 3M mounting tape. Included in your kit is a small Alcohol cleaning wipe. After ensuring that the backside of the license plate is clean and dry, peel off the red covering on the 3M tape and then adhere the license plate to the exposed 3M tape.

NOTE: The bond between the 3M tape and the bumper is VERY STRONG. Be sure of its positioning before touching the license plate to the tape because you will only get one chance to make the bond.

**Fitting to Car**

In order to fit the mount to the bumper:

- Locate the center of the lower front bumper lip.
- Approach the lip with the complete mount assembly first positioning the foam-covered hooks over the leading edge of the lip.
- Reach under the assembly and (using one finger or thumb) push the center of the rear hook assembly towards the back of the car to compress the mounting springs.
- With the springs compressed hook the rear of the mount to the two round holes on the underside of the bumper and release the springs by removing your finger.

Removal is the opposite of installation

**LABOUR ESTIMATE GUIDE**

**5 Minutes**