



INSTALLATION INSTRUCTIONS FOR CARBON AIR PLENUM COVER FERRARI F360 COUPE, SPYDER, CHALLENGE, & CHALLENGE STRADALE

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

Tools Required:

- 5mm Allen (hex) head wrench

Kit includes:

1 – Carbon fiber air plenum cover

SAFETY WARNING

The installation of this part requires that the installer's hands be very close to engine components which get extremely hot. Only install on a vehicle that has had plenty of time to cool off.

Step 1: The factory (OEM) air plenum cover has 4 visible screws but only 2 of them hold the lid in place. Using a 5mm Allen head wrench, fully remove the **front left** and **back right** screws only.

Step 2: Lift the OEM cover out and replace it for the carbon part making sure that it sits flat.

Step 3: Re-install the screws removed in Step 1. **Be careful not to over-tighten these screws as it can cause the carbon cover to crack. Snug is all that is necessary.**

A note on caring for your carbon part:

Your carbon component has been clear coated at the factory to give it its high gloss luster. Small scratches and imperfections can be polished out using the same compounds and waxes used on automotive paint. If your plenum cover is fitted with a Ferrari horse emblem, take care in cleaning as it can be easy to catch a polishing cloth on the edge of the emblem and damage it.

LABOUR ESTIMATE GUIDE

5 Minutes