



INSTALLATION INSTRUCTIONS FOR CARBON FIBER AIRBOXES FERRARI F430 COUPE, SPYDER, & CHALLENGE

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

Tools Required:

- Flat head (slot) screwdriver
- 8mm open ended wrenches

Kit includes:

- 2 – Carbon fiber replacement airbox lids
- 2 – Foam element performance air filters

Step 1: Using 8mm wrenches, remove the nuts and bolts that hold the MAF sensors to the OEM metal airbox lids. **Be careful not to drop them!**

Step 2: Using a flat headed screwdriver, undo the 8 screws (4 per lid) that attach the OEM metal airbox lids to the rest of the OEM airbox assembly. The airbox lids can now be removed from the car.

Step 3: With the airbox lids off, remove the OEM paper air filters and replace them for the performance units included in the kit.

Note that the carbon fiber lids can be used with either the OEM filters or the foam performance units.

Step 4: The carbon airboxes can now be installed. Installation is the reverse of removal.

Step 5: Tighten down all screws being careful not to over-tighten.

LABOUR ESTIMATE GUIDE

15 Minutes