



## INSTALLATION INSTRUCTIONS FOR FERRARI 458 CARBON FIBER AIRBOX

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

### **Tools Required:**

3mm Allen head (hex) tool  
Flat headed screwdriver  
8mm open ended wrench  
Torx T20 tool  
Rubbing alcohol or similar cleaner

**Step 1:** Using a 3mm Allen head tool & 8mm wrench remove the screws that hold the factory airbox to the MAF sensors.

**NOTE:** There are thin washers on either end of each fastener and care must be taken to not drop these during removal.



**Step 2:** Using a T20 Torx headed tool, removed the screws that hold the factory airbox in place around its perimeter.



## LABOUR ESTIMATE GUIDE

20 Minutes

**Step 3:** To remove the factory airbox, first lift its bottom perimeter away from the bottom part of the airbox and then push it forwards (compressing the corrugated bellows the MAF sensors are connected to) to yield the necessary clearance to lift the factory airbox out.



**Step 4:** Install the carbon airbox in the reverse order as the removal taking particular care not to drop the washers noted in Step 1.

**Step 5:** If you have purchased a replacement Ferrari badge for your airbox install it by first cleaning the mounting surface on the carbon airbox with some rubbing alcohol to remove any oils and then peel the red backing from the badge's mounting tape and stick the new badge in place.

#### **Transfer of OEM Ferrari Badge from stock airbox to new carbon airbox (if applicable)**

**Step 1:** Using a flat headed screwdriver carefully pry off the badge from the stock airbox. The badge is held in place with double sided tape only and requires nothing more than a little prying to get off.



**Step 2:** With the badge removed use some rubbing alcohol or similar cleaner to remove any glue residue on the backside of the badge. Once clean, install the included 2 sided tape to the new badge.

**Step 3:** In the same procedure as Step 5 above, first clean the mounting surface on the carbon airbox with some rubbing alcohol to remove any oils and then peel the red backing from the mounting tape and stick the badge in place.