



INSTALLATION INSTRUCTIONS FOR FERRARI 458 CARBON FIBER ENGINE BAY PANELS

Thank you for choosing to purchase a Carbonio product. Please take the time to fully read over these instructions before attempting to install the kit. This will greatly speed up the installation process and minimize any difficulties you may encounter.

Kit includes:

3 pcs – Carbon fiber engine bay panel kit
1 pc – Allen head tool

NOTE: Due to production variances between cars it is not uncommon for the mounting holes of the panels to not all line up. Ferrari themselves address this by filing larger the holes on the panels when they do not line up. Be prepared to enlarge the mounting holes as necessary to help ensure a clean installation.

Step1: Using the included Allen head tool, loosen and remove the 5 screws that hold one of the factory side panels in place. With the screws removed lift the panel out and set it aside.



Step 2: Repeat Step 1 with the panel on the opposite side.

Step 3: Using same Allen head tool, remove the 4 screws holding the forward firewall panel in place and lift the panel out.

Step 4: Installation is the reverse of the removal starting with the installation and tightening of the forward firewall panel followed by the side panels.

TIP: Start all screws **FIRST** and then tighten them down to the point where the heads just touch the surface of the carbon and then tighten each screw down one at a time. **DO NOT OVERTIGHTEN** the hardware! Just past snug is all that is necessary.

LABOUR ESTIMATE GUIDE

15 Minutes