

Trike Tight Table Top Work Stand

Assembly & Instructions



3. Install each LEG onto the T by loosely screwing two 45mm bolts into the lower holes of the LEG.



LEGS



CRADLES

Introduction

The TrikeTight Table Top Workstand is a great way to work on your trike without compromising comfort!

Tools Required

You will only need a 4mm Allen (hex) wrench.

Assembly

1. PULL the BAG OF SMALL PARTS from the box. There should be two rubber STRAPS, three washers, and three bolts with knobs. The rest of the bolts are 45mm long.



BAG OF SMALL PARTS



LOCK PIN

2. Pull the T-ASSEMBLY from the box. Remove the lock pin from the plate, unfold the assembly until the tubes are perpendicular to one another, and replace the lock pin to secure the T-ASSEMBLY in this orientation.



T-ASSEMBLY

4. Install each CRADLE into the T-ASSEMBLY. Two of the cradles have swoopy ends. These should be placed to the front of the stand, near the TrikeTight lasermark. The cradle *without* the swoopy ends should be used in the rear, so that the cradle doesn't snag your chain when you move your trike. With each LEG in its proper corner, loosely screw one 45 mm bolt into the lower hole of the T-ASSEMBLY plate and through the lower hole of the LEG. Then, thread the bolt (the one with the knob) through the T-ASSEMBLY plate and through the upper hole of the LEG, using the two-sided knob as a nut on the far side.

5. With everything in place, **tighten all the bolts.** Tighten them enough that everything is secure, but make sure the LEGS can swing as necessary, and that the T-ASSEMBLY can fold when the lock pin is removed. Note that the swing of the LEGS will help when assessing the right fit for your trike. Additionally, the cradles can be screwed in or out to dial in the fit, just use the knob on the bottom of the threaded shaft to lock the cradle in place.

6. Finally, pull the STRAPS from the BAG OF SMALL PARTS. The STRAPS hook to one end of the cradle, over the tubing of your trike, and onto the other end of the cradle. This keeps your trike from tipping about when set in the work stand.



STRAPS

Stowing the Stand

Pull the **LOCK PIN** from the plate of the T-ASSEMBLY and fold the stand until the lock pin can be reinserted through the plate and into the center tube to secure it in a folded position.



FOLDED TRIKE TIGHT

