

Instructions:

1. Print out this .pdf at 1:1 scale (zoom 100%)
2. Verify the printout using a rule at the 6in mark, or a bank note at the designated mark.
3. Cut out scale & trim to Start line.
4. Wrap scale around tube.
5. Make a mark where the scale overlaps the Start line.
6. Find the nearest size to the mark.

NOTE: If your mark is not near any listed diameter, the tubing may be an odd size. Calipers may be necessary to find the measurement in this case.

