

FLAT SHOP LIGHT

Install Guide and Manual

COMPONENTS








Plastic Anchor

EASY INSTALLATION Suspension Install



•Plaster board - #8 eye hook screw with plastic anchors, or expansion bolts (not included); •Plaster board thickness should be 3/8 inch.





3. Attach two anchors to ceiling. Spacing between

in the screw eye hooks into the anchors.

hooks should be 38.15" inches apart, then screw





Turn Power OFF

Connect to Power Outlet


additiona

4. Depending on your lighting plan, space the anchors accordingly

·Link up to 8.



5. Install one S hook into each end of the chain. then crimp the end attached to the chain with pliers. Leaving the other side open. Repeat with second chain.



- 6. Install one S hook into each end of the chain, then crimp the end attached to the chain with pliers. Leaving the other side open. Repeat with second chain.
- 7. Hang the lose end of the S hook chain on screw eye hook in ceiling.



- 8. Plug in power cord to electrical outlet. 9. Turn on circuit breaker and test light.
- Turn Power ON

WARNING

All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards. Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections. Please review instructions carefully before proceeding.

WARNING: Risk of fire or electric shock. Do not alter, relocate or remove wiring during installation.

This fixture complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Not for use with dimmers. Do not install directly over a heat source.

SPECIFICATIONS

Voltage	120V
Wattage	40W
Suitable for Locations Ingress	Damp
Housing	Aluminum+PC
Weight	2.70lbs
Warranty	7 years