

SUNCO'S 4" SLIM DOWNLIGHT

Install Guide and Manual

COMPONENTS



EASY INSTALLATION




- Wire Nuts Black-live wire White-neutral wire
- 1. Turn off circuit breaker that provides power to the light switch for the recessed lights. 2. Cut a hole in the ceiling in the desired location
- accordingly to the dimension indicated.




- 3. Run electrical wire from the power source (switch) through the mounting hole.
- 4. Open the junction box and remove the appropriate knockout(s) on the side plate.

- 5. Connect the supply wires to the junction box wires using the wire nuts provided. ·White to white ·Black to black
 - 6. Tuck the connected wires inside the junction box and close the cover.




7. Connect the junction box to the slim down light. Tighten the connector by hand.



Ceiling

- 9. Push up the spring clips to insert the luminaire in the opening in the ceiling.
- 10. Turn on circuit breaker and test the light.



WARNING

All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards. Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections. Please review these instructions carefully before proceeding

WARNING: Risk of fire or electric shock. Do not alter, relocate or remove wiring during installation.

WARNING: Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation

SPECIFICATIONS

Voltage	120V
Wattage	10W
Usage	Indoor
Housing	Polycarbonate
Weight	0.68lbs
Warranty	7 years

