

# **SMOOTH DOWNLIGHT 5/6"**

Install Guide and Manual

### **COMPONENTS**



#### **EASY INSTALLATION**



Turn Power OFF

1. Turn off circuit breaker that provides power to the light switch for the recessed lights



2 Locate the housing.

•Remove previous fixture, fixture may be hot so allow time to cool after turning off power.





- 3. Determine the size of the opening (5" or 6").
- Adjust the downlight using the screw on the side.



5. Determine the type of connector available.

•TP24 Connector •E26 Base





- 6. Thread the appropriate adapter to make connection in the housing.
  - •Note: the wires may come lose from the connectors so ensure they are attached.
- 7. Tuck all wires into the can.
- 8. Line up trim ring with opening



- 9. Hook downlight springs into housing.
- 10. Push downlight into can until secure.
- 11. Turn on circuit breaker, test light.

#### WARNING

All electrical connections must be in accordance with local and National Electric Code (N.E.C.) standards. Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections. Please review these instructions carefully before proceeding.

WARNING: Risk of fire or electric shock. Do not alter, relocate or remove wiring during installation.

WARNING: Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation

## **SPECIFICATIONS**

Voltage	120V
Wattage	13W
Suitable for Locations Ingress	Damp
Housing	Polycarbonate
Weight	0.58lbs
Warranty	7 years