



*“Setting the World’s
Performance Standards”*

743 E. Iona Road, Idaho Falls, ID 83401, (208) 529-0244 Fax (208) 529-9000

SLP Performance Muffler for 2014 Polaris XP 1000 RZR and RZR-4 Part# 09-111

THIS MUFFLER IS NOT U.S. FORREST SERVICE APPROVED

Kit Contents:

- | | |
|---|--|
| 1 - SLP Performance Muffler (#090-1111) | 2 - Nut for Spark Arrestor (#999-1082) |
| 1 - 6mm Nylock Nut (#999-0199) | 2 - Bolt for Spark Arrestor (#999-1083) |
| 2 - Screen Type Spark Arrestor (#1262123) | 1 - Installation Instructions (#015-09111) |
| 1 - SLP Decal (#60-60) | 2 - Spring Tab (#090-697) |

Tools Required:

- | | |
|-----------------|-------------------------------|
| #40 Torx Socket | 6” Extension Spring Hook Tool |
| Ratchet | Short Socket Extension |
| 10mm Socket | 10mm End Wrench |
| 8mm Socket | |

Installation:

1. Remove the four #40 Torx screws from the rear muffler cover and remove rear muffler cover from the RZR.
Note: Optional rear bumper (if equipped) will need to be removed and re-installed once SLP muffler install is complete.

2. Unhook springs holding stock muffler and remove muffler (SLP Extension Spring Hook Tool # 20-90 is recommended).

3. Remove the two stock muffler retention springs from RZR frame.

Note: After the stock muffler is removed, the stock heat shield behind the stock muffler may need to be removed to allow removal of the top retention spring from the RZR. Re-install stock heat shield once spring is removed.

5. Install spring tab onto the upper left hand rear silencer cover arm using the supplied nut with the spring tab pointing rearward (see illustration #1).

6. Remove the bottom nut on the rear end mount (see illustration #2) and install the provided spring tab pointing toward the left (drivers) side of the RZR.

Starting Line Products • 743 E. Iona Rd. Idaho Falls, ID 83401
Sales (208)529-0244 • Tech (208)524-3397 • Fax (208)529-9000 • e-mail: slp@slp.cc
For instructions in color please visit us on the web @ www.startinglineproducts.com

7. Hook stock springs into SLP spring tabs installed in steps #5 and #6.
8. Verify stock grafoil seal is installed on header, install SLP muffler and spring into place using stock springs.
9. Re-install rear muffler cover and fasten with the four #40 Torx head screws removed in step #1.
10. Install included spark arrestors using provided bolts and locknuts.

