



Murray Hook

Please be careful of electrical wiring in walls before drilling and installation.

PARTS PROVIDED

- Wall hook
- Lag screw
- 2 X 3" x 5/16 zinc plated nuts

STEP 01



Drill a 6mm hole in the desired location into a stud or masonry wall (masonry drill bit and plug required for masonry wall).

STEP 02



Tighten the two nuts together at the end of the screw with a spanner

STEP 03



Use a spanner to tighten the screw into a pre-drilled hole in the wall, leaving enough thread to mount the hook. Remove the nuts once the screw is secure.

STEP 04



Hand screw the coat hook onto the wall. **DO NOT** use an electric or battery-operated drills when screwing in handles.

STEP 05



Now go and make something remarkable.