

# Wedding Gown Favor Box

## Assembling the box:

- Open the box to form a rectangle.
- Fold in the side flaps of the bottom at scored lines.
- Fold the large bottom flap over. Fold down scored tab and tuck into the bottom of box.
- Pinch sides of box together to crease the diagonal scored lines on the sides. As you do this, the middle section will fold in toward the inside of the box.
- Line up the pre-punched holes with the holes on the front and back of the box.
- Loosely thread included, pre-cut ribbon through the holes from the front to the back, then from the back to the front. The result is the two ribbon ends will be on the front of the box with the personalization. It is recommended to use a bobby pin or large needle to make threading ribbon easier.
- Line the inside of the box and fill with treats. If using wrapped treats, lining is optional.
- Carefully pull ribbons tight while pressing back, sides and front together to close box.
- Tie the ribbon in bow to complete favor.

