# **SEAVIEV//** *ELEVATE YOUR ELECTRONICS*

0

## INSTALLATION INSTRUCTIONS

For Seaview Modular Mount: **PMA-1210-M2**, **PMA-1810-M2** 

Refer to website for most up to date instructions and videos.

WWW.SEAVIEWGLOBAL.COM



### **TOOLS NEEDED**





Sudbury Elastomeric Marine Sealant is recommended. To purchase call 800-655-7922 or visit www.seaviewglobal.com



Mark the four bolt holes and center radar cable hole using the foam gasket as a template.





Using a 3/8" drill bit, drill the four bolt holes.

Use a 11/2" hole saw to cut a whole for the radar cable.



Insert the rubber grommet into the groove located in the light bar hole at the back of the mount.



If you are using a light bar, do not use the provided pin.





**4B** If you are not using a light bar insert the pin. Then insert the white plastic plug into the light bar hole. It should snap onto the pin.



Place rubber gasket in the groove on the top of the





Insert the rubber radar cable grommet into the center of the Seaview Top Plate (sold separately). Make sure that the lip in the center of the Top Plate hole sits in the groove of the rubber grommet.

Then place the Top Plate on top of the mount, making sure that eight center bolt holes line up.





Using the eight 5/16 - 18x1" bolts from the Seaview Top Plate kit, bolt down the Top Plate.

Refer to the provided Seaview Top Plate installation instructions for more information.





Place the foam gasket and Seaview mount over the bolt holes.







If you prefer not to use the foam gasket apply sealant or equivalent to seal the base.



х4



Using your own bolts and the four supplied nylon should washers bolt down the Seaview mount to the mounting surface.

Apply marine adhesive sealant to the threads.

χ4





### **SEAVIEV//** ELEVATE YOUR ELECTRONICS



Tel: 800-655-7922 www.seaviewglobal.com

#### EUROPEAN OFFICE

Tel: +33 4 94 53 27 70 www.seaviewprogress.com 3-111318