



React Brackets for Snowden Seats - 60-66 C10

Thanks for your purchase of React components. Please ensure everything is in the box according to the list below. If not, contact us within 2 business days of receiving so we can help. If after 2 business days, it is difficult for us to ensure getting you the missing parts.

All React parts offer a lifetime warranty against manufacturer defect and craftsmanship. This warranty is voided if product is abused or has been improperly installed.

All React parts are for off-road use only.

Parts Included

- (2) Seat brackets (left and right)
- (4) 5/16 Bolts
- (4) 5/16 Nyloc nuts
- (8) 5/16 Washers

Start by laying out all parts and accounting for all items listed above. Once you confirmed it is all there, we can proceed. Make sure to use all proper safety procedures and equipment when working on any vehicle. Failure to do so can result in injury or death.

1. Remove old / previous seat if it exists.
2. Bolt the React bracket into the factory seat floor mounts using the (4) bolts and (4) washers. The shorter leg of the bracket will be the front, which will leave the "flat face" side of the bracket towards the outside of the truck.
3. If using a 58" seat, you will use the outside holes closest to the outside of the truck. If using with a 60" seat, then the inside holes closest to the center of the truck will be used.
4. Place seat onto the brackets and use the remaining (4) washers and (4) nyloc nuts to secure to the bracket.

If you have any technical questions or issues with your React product, please contact us using the information below. Again, thank you for your purchase!