



LL-C252 / LL-C253

ASSEMBLY INSTRUCTION

ASSEMBLY STEPS:

1. REMOVE WALL BRACKET FROM THE LAMP FIXTURE AND ATTACH THE MOUNTING CROSS BAR [D] ONTO THE CEILING BRACKET AND FASTENING WITH THE MOUNTING SCREWS [E] (2PCS).
2. CONNECT THE BLACK CORD OF LAMP WITH THE ANODE WIRE ON WALL BRACKET BY CONNECTOR[A],CONNECT WHITE CORD OF LAMP WITH CATHODE WIRE ON WALL BRACKET BY CONNECTOR [A]. COBNNECT THE GROUND WIRE TO THE WALL GROUND WIRE BY CONNECTOR (B).
3. TIGHTEN THE CANOPY (LAMPBODY) [K] ON THE MOUNTING CROSS BAR [D] TIGHTENED IT BY NUT [F].
4. PUT [H],[L],[I] IN TURN TO THE SCREW TUBE [G], THEN TIGHTEN BY FINIAL [J].

CAUTION:PULL ANY EXCESS WIRE THROUGH BOTTOM OFTHE LAMP. .
TO CLEAN,USE A SOFT CLOTH ONLY.

NOTE:TURN THE POWER OFF(UNPLUG FROM THE WALL OUTLET) BEFORE REPLACING THE BULB.MAKING SURE THE BULB HAD SUFFICIENT TIME TO COOL DOWN.DO NOT SUBJECT TO THE LAMP TO ANY SHOCK WHITE LIT AS SHATTERING OF LAMP MAY RESULT.

