

LINEA DILARA

LL-C33/35

ASSEMBLY INSTRUCTIONS

ASSEMBLY STEPS:

1. REMOVE ALL PARTS FROM PACKAGE. BE CAREFUL NOT TO DAMAGE ANY COMPONENTS.
2. SCREW (B) INTO THE SCREW (H) TO (REMOVE) PARTS (K) (H) TO ADJUST THE HEIGHT OF THE FIXTURE AS NEEDED.
3. REMOVE WALL BRACKET FROM THE LAMP FIXTURE AND ATTACH THE MOUNTING CROSS BAR (D) INTO THE FIXTURE BRACKET AND FASTEN WITH THE MOUNTING SCREWS (E) (G) (I).
4. CONNECT THE BLACK CORD OF LAMP WITH THE ANODE WIRE ON WALL BRACKET BY CONNECTOR (A). CONNECT WHITE CORD OF LAMP WITH CATHODE WIRE ON WALL BRACKET BY CONNECTOR (A). CONNECT THE GROUND WIRE TO THE WALL GROUND WIRE BY CONNECTOR (A).
5. TIGHTEN THE CANOPY (H) ON THE MOUNTING CROSS BAR (D) TIGHTEN IT BY NOT (J).
6. SCREW THE (H) TO (P) (H) IN THE GLASS SHADE (M) (N) (O) AND TIGHTEN BY SCREW RODS (L).

CAUTION: PULL ANY EXCESS WIRE THROUGH BOTTOM OF THE LAMP TO CLEAN USE A SOFT CLOTH ONLY.

NOTE: TURN THE POWER OFF (UNPLUG FROM THE WALL OUTLET) BEFORE REPLACING THE BULB. MAKE SURE THE BULB HAS SUFFICIENT TIME TO COOL DOWN. DO NOT TOUCH THE GLASS SHADE TO ANY SURFACE WHILE IT IS SHATTERING OF LAMP MAY RESULT.

