

LL-P117BN / LL-P117BRO/LL-P117DB

ASSEMBLY INSTRUCTIONS

ASSEMBLY STEPS:

- 1. SCREW [F] TO [E] TIGHTLY. THEN SCREW CANOPY [M] TO [F] TIGHTLY.
- 2. REMOVE CEILING BRACKET FROM THE LAMP FIXTURE, AND ATTACH THE MOUNTING CROSS BAR
 [I] INTO THE CEILING BRACKET ON THE CEILING AND FASTENING WITH THE MOUNTING SCREWS [H].
- 3. CONNECT THE BLACK CORD OF LAMP WITH THE ANODE WIRE ON CEILING BRACKET BY CONNECTOR [K], CONNECT WHITE CORD OF LAMP WITH CATHODE WIRE ON WALL BRACKET BY CONNECTOR [K]. CONNECT THE GROUND WIRE TO WALL BRACKET BY CONNECTOR [L].
- 4. PLACE THE CANOPY [M] ON THE MOUNTING CROSS BAR [I] AND ATTACH BY SCREWING NUTS [G] ON TO SCREWS [J].
- 5. PUT [C] AND [B] ON TO [D], THEN TIGHTEN FINIAL [A].

CAUTION: PULL ANY EXCESS WIRE THROUGH BOTTOM OF THE LAMP. PLEASE USE TYPE A BULB. DO NOT USE LIGHT BULB RATED GREATER THAN 60 WATTS OR THE LAMP MAY BURN AND CAUSE A FIRE! TO CLEAN, USE A SOFT CLOTH ONLY.

NOTE: TURN THE POWER OFF (UNPLUG FROM THE WALL OUTLET) BEFORE REPLACING THE BULB. MAKE SURE THE BULB

HAS SUFFICIENT TIME TO COOL DOWN. DO NOT SUBJECT THE LAMP TO ANY SHOCK WHILE LIT AS SHATTERING OF LAMP MAY RESULT.

