



LL-WL111

ASSEMBLY STEPS:

1. REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT TO DAMAGE ANY COMPONENTS.
2. FIX THE CROSSBAR[A] ONTO THE WALL AND TIGHTEN BY SCREWS[B].
3. CONNECT THE BLACK WIRE[D] OF LAMP WITH ANODE WIRE ON BACK PLATE BY CONNECTOR, CONNECT WHITE WIRE OF LAMP WITH CATHODE WIRE ON BACK PLATE BY CONNECTOR. CONNECT THE GROUND WIRE[C] TO THE GROUND WIRE IN CANOPY BY CONNECTOR.
4. PLACE THE LIGHTING FIXTURE [E] ONTO CROSS BAR[A], AND THEN SCREWED BY FINIAL[F].
5. SCREW THE BULBS(GU24 BULB) ONTO SOCKET(BULBS NOT INCLUDED).
6. PUT THE ACRYLIC SHADE ONTO THE TRAY[H], MAKE SURE THAT THE TEETH ON TRAY GO THROUGH THE SPACE OF ACRYLIC SHADE BOTTOM, THEN ROTATE THE ACRYLIC SHADE TO TIGHT.

CAUTION: PULL ANY EXCESS WIRE THROUGH BOTTOM OF THE LAMP. PLEASE USE GU24 BULB, DO NOT USE LIGHT BULB RATED GREATER THAN 13 WATTS OR THE LAMP MAY BURN AND CAUSE A FIRE TO CLEAN, USE A SOFT CLOTH ONLY.

NOTE: TURN THE POWER OFF (UNPLUG FROM THE WALL OUTLET) BEFORE REPLACING THE BULB. MAKE SURE THE BULB HAS SUFFICIENT TIME TO COOL DOWN. DO NOT SUBJECT THE LAMP TO ANY SHOCK WHILE LIT AS SHATTERING OF LAMP MAY RESULT.

