

LL-WL31

ASSEMBLY INSTRUCTIONS

ASSEMBLY STEPS:

1. REMOVE WALL BRACKET FROM THE LAMP FIXTURE AND ATTACH THE MOUNTING CROSS BAR [K] INTO THE WALL BRACKET AND FASTENING WITH THE MOUNTING SCREWS [J] (2PCS).
2. CONNECT THE BLACK CORD OF LAMP WITH THE ANODE WIRE ON WALL BRACKET BY CONNECTOR [I],CONNECT WHITE CORD OF LAMP WITH CATHODE WIRE ON WALL BRACKET BY CONNECTOR . CONNECT THE GROUND WIRE TO THE WALL GROUND WIRE BY CONNECTOR (H).
3. TIGHTEN THE CANOPY [F] ON THE MOUNTING CROSS BAR [K] TIGHTEN IT BY NUT [D].
4. TIGHTEN THE TUBE(F) INTO THE PART(E).
5. PUT THE GLASS SHADE[A]ONTO [C] AND TIGHTEN BY SCREW RODS[B].

CAUTION: PULL ANY EXCESS WIRE THROUGH BOTTOM OF THE LAMP.
TO CLEAN, USE A SOFT CLOTH ONLY.

NOTE: TURN THE POWER OFF (UNPLUG FROM THE WALL OUTLET) BEFORE REPLACING THE BULB.
MAKE SURE THE BULB HAS SUFFICIENT
TIME TO COOL DOWN. DO NOT SUBJECT THE LAMP TO ANY SHOCK WHILE
LIT AS SHATTERING OF LAMP MAY RESULT.

