

DIRECT4x4

Volkswagen Transporter T5/T6 Angular OE Style Side Bars

1: Parts List

Part Name	Quantity
Side Bars	2
Front Brackets	2
Rear Brackets	2
T-bolts	12
Bolts	4
Large Washers	5
Washers	12
Clips	17
Spring Washers	17
Nuts	17



Please ensure that you have received all of the components listed above before fitting. If you believe there is anything missing, contact us for assistance.

2: Fitting the Brackets (FRONT)

First remove the undertrays to gain access to the sill, when this is done locate the grommet/bung in the sill and remove, place the t-bolt into the holes and hand tighten in place as seen below. There are only two t-bolts per bracket, this makes them easy to fit.



The side bars fit onto the bracket using one of the small bolts through the centre, this then fixes into place on the bar as seen below, then secure all fixings.



3: Fitting the Brackets (REAR)

Locate the grommet/bung in the sill at the rear of the vehicle and remove. Place the t-bolts into the holes and again hand tighten the same as on the front brackets, this will make it easier to get the small bolt in place in the centre.



You fit the bars to the brackets by using one of the small bolts provided in the kit through the centre of the bracket to the bar, when fixed in place tighten all bolts.



4: Fitting the Brackets (EXTRA)

Depending on the cosmetic look you want to your vehicle the bars can be turned around so they fit further forward on the vehicle or further back. When complete replace the undertrays, you may need to cut the undertrays around the brackets to get them to fit securely you can do this with either a dia-cutter or small grinder.



General Care & Maintenance

!IMPORTANT!

We strongly advise you check under the car at several intervals after the initial fitting to ensure safety. After 7 days, check and tighten any bolts and we recommend inspecting the bolts, brackets and boards at least once every 6 months.

Cleaning Information

You can use most cleaning on these side steps. However, we strongly advise against using petrol based solutions or corrosive cleaning solutions which include TFR (Traffic Film Remover) or similar chemicals (brake strippers etc.) These will tarnish and possibly even corrode parts of the steps.

When cleaning underneath the side steps, be mindful of any protruding bolts or sharp edges, especially at the ends of the boards.

To increase the lifespan of your new side steps, we recommend occasionally cleaning the actual brackets.