

HH Hook Installation

Our HH hooks are installed quite easily in a 2 step process.

1. Mark your location and then follow the instructions for installing the snap toggle bolt provided with your hook;
<https://www.youtube.com/watch?v=SC1ZuxuZ2PU>
2. Screw your hook into the drywall anchor and turn it clockwise until it is tight. Continue to turn the hook until it is firm against the wall and continue to the right until the hook is parallel with the floor. Do your best not to turn right of parallel otherwise, it could weaken the hold it has on the wall.

- - - - -

KROFT believes firmly in providing after sale service. If you purchase any of our products you can always contact us for assistance with installation, use, care or maintenance.