

ASSEMBLING INSTRUCTION

WINDSCREEN KIT BMW R-NINET

BT1300-C

KIT

- X1. WINDSCREEN
- X1. LEFT/RIGHT BRACHETS KIT
- X4. M5X16
- X4. M5X14
- X4. TEFLON WASHER Ø5
- X6. RUBBER WASHER
- X4. LARGE WASHER Ø5
- X4. SELF-BLOCKING NUT
- X2. M8X45
- X2. KNURLED NUT Ø8

WWW.BARRACUDAMOTO.COM

PROCEDURA DI MONTAGGIO:

1. FIX THE THREATED TURNED BETWEEN THE BRACKETS USING THE SUPPLIED M5X10, AS SHOWN.
2. REMOVE THE TWO ORIGINAL SCREWS THAT FIX THE HEADLIGHT.
3. THEN ASSEMBLE THE SPECIFIC BRACKETS, USING THE SUPPLIED M8X45 AND THE Ø8, AS ILLUSTRATED.
3. MOUNT THE WINDSCREEN TO THE SPECIFIC BRACKETS USING THE SUPPLIED BOLTS.
4. TIGHTEN EVERYTHING.

