



RLA HS Water Based Timber Adhesive

PRODUCT DESCRIPTION:

RLA HS is a high viscosity, high solids, trowellable, water-based vinyl acetate adhesive.

FOR BONDING:

Wood block and mosaic parquetry to timber substrates.

It is also recommended for bonding Masonite, Plywood and Timber Sheeting underlayments to Timber and Concrete Substrates.

Please Note: RLA HS Timber Adhesive is not recommended for installing any timber flooring over concrete substrates, this application should be carried out with RLA MS Timber Flooring Adhesive.

SURFACE PREPARATION:

Subfloors must be dry, sound, smooth, clean and in accordance with the relevant Floorcoverings Australian Standards. Subfloors must also be free of wax, grease, oil, polishes, old adhesive, curing compounds, high levels of moisture and any other surface contaminants that may affect adhesion.

If mechanical preparation is required prepare the floor using recommended preparation methods such as shot blasting, scarifying, diamond grinding, to provide a roughened, clean, sound, solid and open porous surface.

The minimum subfloor temperature before commencing surface preparation and adhesive application is 10°C.

Test all concrete and timber substrate flooring for moisture content, according to the current Australian Standards prior to priming or the installation of any floorcoverings.

Indentations and uneven concrete subfloors should be treated with the RLA range of levelling compounds and be in accordance with manufacturer's recommendations.

APPLICATION:

Adhesive should be spread evenly with a 3.2mm V notched trowel.

It is recommended the notching's be 3.2 mm deep for timber sheeting underlayment and wood block parquetry.

It is essential that 100% of the back of the parquetry and timber sheeting is in contact with the adhesive.

Apply adhesive to an area that can be covered within the open time of the adhesive.

This will vary according to the temperature and humidity prevailing.

The parquetry and timber sheeting underlayment should be placed into wet adhesive film and roll to ensure transfer has occurred.

Fixing Masonite, Plywood Timber Sheeting Underlayment's to a Timber or Particleboard sub-floor, staple/nailing is recommended along with application of adhesive.

CLEAN UP:

Clean tools immediately after use with warm soapy water. Dried adhesive may be cleaned off using AFTEK Handy Wipes.

COVERAGE:

Approximately 1.5 square metres per litre depending upon the condition and absorbency of the substrate and the type of applicator used.

CONTAINER SIZES

15 litre plastic containers

SHELF LIFE / STORAGE:

12 months when stored in original unopened packaging
To be stored in a dry area off the ground.

NOTES & PRECAUTIONS:

- **Please Note:** RLA HS Timber Adhesive is not recommended for installing engineered timber flooring or any timber flooring over concrete and timber substrates. This application should be carried out with RLA MS Timber Flooring Adhesive.
- Do not apply below 10°C or above 30°C.
- Ensure the substrate is absorbent to enable sufficient bond.
- Ensure Masonite, Plywood etc Timber Sheeting Underlayment's are installed to manufactures installation guidelines.
- Do not apply over existing coatings as bond will be affected

SAFETY & HANDLING

A Safety Data Sheet is available on request.

Product is classified as NON-DANGEROUS GOODS. According to the WHS Regulations and the ADG Code.

Warranty Statement:

RLA Polymers guarantees this product against manufacturing defects and guarantees it to be manufactured to our published specification.

We certify that when fully cured this product is suitable for use and will perform as described in our technical data sheet or other published materials.

RLA Polymers will replace product free of charge when purchased from any legally verifiable source, and where product is proven to have been stored, handled and install according to instructions published on our packaging and within the stated shelf life. The Installation of all materials must be carried out in accordance with the relevant Australian Standard and the Floorcovering Manufacturers instructions and the floorcoverings must have been subject to normal traffic conditions.

Warranty doesn't not apply if damage, loss, failure to follow instructions or other circumstances are out of our control.

Sufficient time and access to investigate any complaint must be accorded to RLA Polymers.

The consumer is responsible for any expenses incurred in making a claim.

A claim form can be requested by:

Phone: 1800 242 931

Email: info@rlapolymers.com.au

Mail: 215 Colchester Road Kilsyth Victoria 3137 (attention Customer Service)

Australian Consumer Law

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The benefits under our warranty are in addition to other rights and remedies available to the consumer under the law in relation to the goods and services to which the warranty relates.

Disclaimer

All Statements and technical information contained herein are based on tests we believe to be reliable but the accuracy thereof is not guaranteed.

Users assume all risk and liability resulting from the use of the product and must confirm the suitability thereof by their own tests. Conditions of Sale contain a limited warranty against manufacturing defects.

Issued: January 2021