



ASSEMBLY INSTRUCTIONS

#74336

Big Foot™ Work Station Extended-Carry Bag How-To Insert (2) Side-Support Panels

STEP #1	STEP #2	STEP #3	STEP #4	STEP #5	COMPLETE
<p>Unzip Big Foot™ Work Station Extended-Carry Bag.</p>	<p>Inside bag, locate (2) loose side-support foam panels.</p>	<p>Unzip lining on both side walls for panel insertion.</p>	<p>With foam facing inwards, slide both panels into side-wall linings.</p>	<p>Slightly bend foam corners under until fully snug in wall linings—zip both sides shut.</p>	<p>Both side-walls are now lined and sturdy to hold shape.</p>

**BIG FOOT.
BIG FEATURES.**



#10 YKK Zipper



Sternum Strap



Ammo Chamber



Adjustable Belt



1000-Denier Nylon



Tactical Staps



Gun Holder Pouch



Rain Cover