

Trail / Switchback Battery Box Installation

Step 1: Remove exhaust side panel.

Step 3:

Use supplied M5 flanged bolt and washer/nyloc nut to attach the battery box to footwell in the holes that were drilled in Step 2.

Step 2: Place the battery box in the location and drill two 13/64" or 7/32" holes through the footwell using the existing holes as guides highlighted by the green circles.



Step 4: Install Battery and Cover with supplied ¼-20 hex head locknuts. The top mounting flange may need to be bent down slightly to make the studs line up with the holes in the cover. This is normal because it was designed to slightly pinch the top of the battery to help it hold in its location.



NOTE: If you would rather permanently affix the battery box to the footwell you can use flanged 3/16" rivets with backing washers in place of the bolts.



Please contact Cole with any installation related questions at:
989-372-1723 or cole@cvcustoms.com