



3050, 2600 Portland St SE
Calgary AB Canada T2G 4M6

1-800-Fitter-1 ~ www.Fitter1.com

FITTER BOTTOM TRACK REPLACEMENT INSTRUCTIONS

Tools required: screwdriver, tack hammer

- 1) Gently pry the bottom track free of the wooden side with a flat head screwdriver.
- 2) Carefully flex the track up and slowly pull it away from the base.
Warning: *do not allow the wood core to pull away with the taped track.*
- 3) With track removed, push any protruding slivers back into their original position.
- 4) Next, remove the wax paper from the adhesive strip inside the new bottom track.
Fit the new track at one end and gently slide your hand along the track, fitting it into place along the entire track length.
- 5) Repeat these steps on the opposite side and you are finished.