WOODEN CAMERA® BATTERY BELT CLIP MOUNTING PLATE

INSTALLATION GUIDE



© Wooden Camera, Inc. 2011-2019

INSTALLATION

HOLE DIAGRAM

- 6x 6x M3x14mm phillips pan head screw (Blueshape/RED)
- 4x M3x12mm phillips pan head screw (Anton Bauer)
- 4x 4x M3x8mm phillips pan head (IDX/Swit)
- 4x 4x M3x8mm phillips flat head (Swit/JetPack)

For attaching to battery mount find appropriate threaded holes by using the Hole Chart below. Insert and tighten Phillips Head Screws into corresponding hole as shown on Hole Diagram.

HOLE CHART

- A= Swit/IDX V-Mount/WC V-Mount
- B= A/Bauer QRC/WC Gold Mount
- C= RED/Blueshape
- D= Swit/Jetpack

