

WOODEN CAMERA®

BATTERY SWING

INSTALLATION GUIDE



© Wooden Camera, Inc. 2011-2019

INSTALLATION

- 4x M3 x 12mm Pan Head Screws
- 4x M3 x 8mm Pan Head Screws
- 4x M3 x 6mm Phillips Flat Head Screws

Attach Battery Plate using corresponding screws (see hole chart)

HOLE CHART

- A= Swit/IDX V-Mount/WC V-Mount
- B= A/Bauer QRC/WC Gold Mount
- C= RED/Blueshape
- D= Swit/Jetpack

HOLE DIAGRAM

