

# WOODEN CAMERA<sup>®</sup>

E-MOUNT TO PL MOUNT PRO (SONY FS5)

## INSTALLATION GUIDE



NOTE: FS5 Top Plate Required

© Wooden Camera, Inc. 2011-2019

## INSTALLATION

Support Ring  
E-Mount to PL Mount  
2x 1/4-20x3/8" socket cap screws

1. Locate and align 1/4-20 Holes on Support Ring and Top Plate, select and partially tighten 1/4-20 Screws with allen wrench.
2. Select PL Mount, locate White Mark on Lens Mount and Sony E-Mount.
3. Aligning both White Marks, fit Lens Mount to E-Mount and gently twist clockwise to lock into place.
4. With PL Mount attached to E-Mount fully tighten 1/4-20 Screws and tighten Thumbscrew to secure.

