

WOODEN CAMERA[®]

PL MOUNT (DSMC1/DSMC2)

INSTALLATION GUIDE



© Wooden Camera, Inc. 2011-2020

INSTALLATION

4x M4x8mm socket caps

1. Locate and remove M4 Torx Screws to remove Cover Plate from Camera Body. Set aside.

2. Select PL Mount and align M4 Holes of PL Mount and Camera Body, select and tighten M4 Socket Caps with allen wrench.

