# MSH

MODERN STAINLESS HARDWARE

Installation Template for
S2 Doorbell
S4 Doorbell

① Turn off electrical power to existing doorbell.
Remove old doorbell button.
Use template provided to mark positions.

② Drill holes using the appropriate drill bit for your surface material

③ Insert plastic anchors into small holes

④ Attach wires to the 2 screw terminals on pushbutton

⑤ Push posts on back of doorbell into the plastic anchors

⑥ Using a soft cloth to protect the surface of the doorbell, GENTLY tap the posts into the plastic anchors, alternating sides, using a plastic or rubber mallet until doorbell is flat against the mounting surface. DO NOT HIT THE CENTER PUSHBUTTON WITH THE MALLET.

Installation Template

www.modernstainlesshardware.com