FITTING DIAGRAM

AUDI S3 8P1 V3: REAR DIFFUSER + FLOW-LOCK FINS

6

PLEASE NOTE:

DRILLING NOT REQUIRED

TO FASTEN TO BUMPER

REPLACES OEM SCREW

PLEASE NOTE:

DRILLING REQUIRED

TO FASTEN TO BUMPER

0

PLEASE NOTE:

DRILLING REQUIRED

TO FASTEN TO BUMPER

PLEASE USE 8mm DRILL BIT

INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

BUMPER REMOVAL NOT REQUIRED

