FITTING DIAGRAM

DRILLING **REQUIRED**TO FASTEN TO BUMPER
PLEASE USE 8mm DRILL BIT

AUDI S3 8V PFL SEDAN V3: FRONT SPLITTER

INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

BUMPER REMOVAL NOT REQUIRED

