

# FITTING INSTRUCTIONS

## AUDI S3: FRONT SPLITTER

### FITTING KIT

**a**

M6 BOLT  
40mm LONG

**X 3**

PLEASE NOTE:  
DRILLING REQUIRED  
TO FASTEN TO BUMPER



**b**

M6 BOLT  
30mm LONG

**X 6**

PLEASE NOTE:  
DRILLING REQUIRED  
TO FASTEN TO BUMPER

