### **FITTING DIAGRAM**

## FORD FOCUS RS: FRONT SPLITTER

#### INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advise from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

# BUMPER REMOVAL REQUIRED

## **FITTING KIT**

a M6 BOLT 50mm LONG

X 5

PLEASE NOTE:

DRILLING **NOT REQUIRED**TO FASTEN TO BUMPER
DO NOT OVERTIGHTEN

b M6 BOLT 40mm LONG

X

PLEASE NOTE:

DRILLING **NOT REQUIRED**TO FASTEN TO BUMPER
DO NOT OVERTIGHTEN

С

M6 BOLT 30mm LONG



X 4

PLEASE NOTE:

DRILLING **NOT REQUIRED**TO FASTEN TO BUMPER
DO NOT OVERTIGHTEN

d

M6 BOLT 30mm LONG



X2
PLEASE NOTE:

DRILLING **REQUIRED**TO FASTEN TO BUMPER
DO NOT OVERTIGHTEN

