

# FITTING INSTRUCTIONS

## FORD FOCUS LV XR5 TURBO: FRONT SPLITTER

### FITTING KIT

**a**

**M6 BOLT  
48mm LONG**

**X 2**

PLEASE NOTE:  
DRILLING **NOT** REQUIRED  
TO FASTEN TO BUMPER



**b**

**M6 BOLT  
30mm LONG**

**X 8**

PLEASE NOTE:  
DRILLING REQUIRED TO  
FASTEN TO BUMPER

