FITTING DIAGRAM


FORD XR5 V3: FRONT SPLITTER INSTRUCTIONS

INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.


www.flowdesignsaustralia.com


BUMPER REMOVAL NOT REQUIRED



M6 BOLT a 30mm LONG 9 **X6** (0) 0

PLEASE NOTE: DRILLING REQUIRED TO FASTEN TO BUMPER PLEASE USE 8mm DRILL BIT









TERMS AND CONDITIONS: MISUSE OF GOODS