

FITTING INSTRUCTIONS

HONDA S2K ASM : FRONT SPLITTER

FITTING KIT

PLEASE NOTE:
BUMPER REMOVAL RECOMMENDED
FOR BETTER FITMENT

a

**M6 BOLT
40mm LONG**

X 3

PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER



b

**M6 BOLT
30mm LONG**

X 10

PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER

