## **FITTING DIAGRAM**

HYUNDAI i20 N BC3: REAR DIFFUSER + FLOW-LOCK FINS


## INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

## **BUMPER REMOVAL NOT REQUIRED**





## **FITTING KIT**

a

OD 18 OD 18

M6 BOLT 25mm LONG

X 6

PLEASE NOTE: DRILLING REQUIRED TO FASTEN TO BUMPER PLEASE USE 6.5mm DRILL BIT

b

OD 25 OD 25

M6 BOLT 35mm LONG

**X** 1

PLEASE NOTE: DRILLING REQUIRED TO FASTEN TO BUMPER

M5 COUNTERSUNK BOLT 25mm LONG

PLEASE USE 8mm DRILL BIT

**X2** 0

> PLEASE NOTE: DRILLING **REQUIRED** TO FASTEN TO BUMPER PLEASE USE A 6MM DRILL BIT FOR PILOT THEN ENLARGE TO 10MM

