

# FITTING INSTRUCTIONS

## MITSUBISHI EVOLUTION X: FRONT SPLITTER

### FITTING KIT

**a**

**M6 BOLT  
30mm LONG**

**X 4**

PLEASE NOTE:  
DRILLING REQUIRED TO  
FASTEN TO BUMPER



**b**

**M6 BOLT  
40mm LONG**

**X 4**

PLEASE NOTE:  
DRILLING REQUIRED TO  
FASTEN TO BUMPER



**c**

**M6 BOLT  
55mm LONG**

**X 4**

PLEASE NOTE:  
REPLACE OEM SCREW  
WITH LONGER SCREWS

