FITTING DIAGRAM

X 1 PAIR

PLEASE NOTE:
DRILLING **REQUIRED** TO FASTEN
TO OEM CROSSBAR

VW MK7 GOLF R: FRONT SPLITTER V3

INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advise from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

BUMPER REMOVAL REQUIRED

TERMS AND CONDITIONS: MISUSE OF GOODS
This Product application is not intended for public road regin Regulatons may vary from Countries outlide of Australia.

