## **FITTING DIAGRAM**

OD 25

Ø

PLEASE NOTE:
DRILLING REQUIRED
TO FASTEN TO BUMPER
PLEASE USE 8mm DRILL BIT

SUBARU G3 WRX/RS NB - FRONT SPLITTER

## **INSTALLATION AND FITTING SERVICES**

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

## BUMPER REMOVAL NOT REQUIRED

This Product application is not intended for public road registered vehicles within Australia. Regulatons may vary from Countries outide of Australia. Please check your Country's and State's road regulatons before installing on a vehicle intenpublic road use.

