FITTING DIAGRAM

a

OD 25

TO FASTEN TO BUMPER PLEASE USE 8mm DRILL BIT

SUBARU G3 WRX/RS NB SEDAN REAR SPATS + ADJUSTABLE REAR WINGLETS

INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

BUMPER REMOVAL NOT REQUIRED

