FITTING DIAGRAM

PLEASE NOTE:

DRILLING NOT REQUIRED

TO FASTEN TO BUMPER DO NOT OVERTIGHTEN

TOYOTA MZEA12R COROLLA: SIDE SPLITTERS

INSTALLATION AND FITTING SERVICES

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

DO **NOT**OVERTIGHTEN FASTENERS

INTO BRASS FITTINGS

HAND TIGHTEN ONLY

SIDE SKIRT REMOVAL NOT REQUIRED

