## **FITTING DIAGRAM**

a

9

 $\bigcirc$ 

USE AN 8mm DRILL BIT

NYLOC NUT

OD 25

OD 25

30mm M6

VW MK3 SCIROCCO FL: REAR SPAT INSTRUCTIONS

## **INSTALLATION AND FITTING SERVICES**

If you are having any difficulties please seek professional advice from the listed International and Domestic Authorised Dealers on our website.

www.flowdesignsaustralia.com

## **BUMPER REMOVAL NOT REQUIRED**

